

Pilot/User



 <p style="text-align: center;">Data Link Services</p>	 <p style="text-align: center;">Voice Services</p>
<p><u>Departure:</u></p> <ul style="list-style-type: none"> •Initial Contact •Traffic Advisories •Weather Advisories •PIREPs •Transfer of Control to ARTCC <p><u>Arrival:</u></p> <ul style="list-style-type: none"> •ATIS (broadcast both voice & data) •Initial Contact •Weather Advisories (SIGMETs/ITWS Products) •RVR/Surface Runway Conditions •PIREPs •Sequencing/Traffic Advisories •Traffic Alerts (primarily voice) •Altimeter Setting/Winds •Transfer of Control to Local Controller 	<p><u>Departure:</u></p> <ul style="list-style-type: none"> •Altimeter Setting/Heading/Climb/Speed Instructions <ul style="list-style-type: none"> • All Emergency Communications • Back-Up for Data Link Communications • All Communications for Non-Data Link-Equipped Aircraft

Figure 5-24. Pilot Terminal Communications Services